

Product sheet (updated 14-02-2022)
camRade rainCover ENG/EFP



Name: camRade rainCover ENG/EFP

SKU: CAM-RAINCVR-ENGEFP

EAN-13: 8718591673344

Short description

Universal rain protection cover for most Sony, Panasonic, Blackmagic URSA, Grass Valley, Hitachi, Ikegami and JVC ENG/EFP-style shoulder broadcast cameras, which includes a storage pouch.



Long description

Protect the Sony, Panasonic, Grass Valley, Ikegami, Hitachi and JVC ENG- or EFP-style broadcast camera setup against inclement weather with the rainCover ENG/EFP. It is an absolute must have that will prevent water damage to your most valuable piece of equipment.

Through years of experience and working closely with multiple camera operators, we have improved the designs to perfect solutions for multiple applications. The rainCover ENG/EFP is suitable for shoulder camera work but is also great while your camera is attached on a VCT-plate, tripod, pedestal, or any other camera support solution.

Durable and functional design

Always carry the camRade rainCover ENG/EFP with you so you do not get caught out when the weather turns. The cover is supplied in a waterproof zippered pouch, which you can use to store and transport the cover when not in active use. It is easy to attach and detach the cover, thanks to the convenient design. Breaking down your setup when a storm is coming, or pausing a production is a thing of the past with the rainCover ENG/EFP.

Clamps around the lens hood

Thanks to its 52 cm (20.5") rubber strip, the rainCover fits correctly on most Canon or Fujinon lenses and lens hoods. The strap supplied with a hook-and-loop fastener makes it possible to tighten the cover on the lens hood but still lets you operate the lens.

Easy access to what is important

With several zippered and hook-and-loop openings you can easily access all essential parts of the camera. From openings for the carrying strap, wireless antennas, microphone, and viewfinder to a transparent window on the side, this rain cover has it all. The back of the cover easily opens to change the camera's battery or quickly access cables.

Key features

- Form-fitted rain cover for a wide range of ENG- and EFP-style cameras
- Protection against inclement weather conditions
- Made of water-resistant fabric with easy access to all essential controls and parts
- Clear Vinyl windows, access to the camera handle and C-Clip strap attachments
- Strong Easy-on / Easy-off construction with hook and loop fasteners and YKK® zippers
- 10-Year Warranty

Compatibility


- | | | |
|-----------------------------|-------------------------|------------------|
| • ARRI AMIRA | • JVC GY-HM790 | • Sony HDC-2550 |
| • ARRI AMIRA Live | • JVC GY-HM850 | • Sony HDC-2570 |
| • Blackmagic URSA | • JVC GY-HM890 | • Sony HDC-3100 |
| • Blackmagic URSA Broadcast | • Panasonic AG-HPX2000 | • Sony HDC-3170 |
| • Grass Valley LDX 100 | • Panasonic AG-HPX300 | • Sony HDC-3300R |
| • Grass Valley LDX 150 | • Panasonic AG-HPX3100 | • Sony HDC-3500 |
| • Grass Valley LDX 80 | • Panasonic AG-HPX500 | • Sony HDC-4300 |
| • Grass Valley LDX 82 | • Panasonic AG-HPX600 | • Sony HDC-4800 |
| • Grass Valley LDX 85N 4K | • Panasonic AG-HPX610 | • Sony HDC-5500 |
| • Grass Valley LDX 86 | • Panasonic AJ-CX4000GJ | • Sony HDW-650P |
| • Grass Valley LDX 86N | • Panasonic AJ-HDX900 | • Sony HDW-800P |
| • Hitachi SK-HD1000(R2) | • Panasonic AJ-HPX2100 | • Sony HSC-100 |
| • Hitachi SK-HD1200 | • Panasonic AJ-HPX2700 | • Sony HSC-300 |
| • Hitachi SK-HD1300 | • Panasonic AJ-HPX3700 | • Sony HXC-100 |
| • Hitachi SK-HD1500 | • Panasonic AJ-PX380 | • Sony HXC-D70 |
| • Hitachi SK-HD2000(R2) | • Panasonic AJ-PX5000 | • Sony HXC-FB80 |
| • Hitachi SK-HD2200 | • Panasonic AJ-PX5100GJ | • Sony PDW-680 |
| • Hitachi SK-UHD4000 | • Panasonic AJ-PX800 | • Sony PDW-700 |
| • Hitachi Z-HD5000 | • Panasonic AJ-SDC615 | • Sony PDW-850 |
| • Hitachi Z-HD6000 | • Panasonic AJ-SDC905 | • Sony PDW-F355 |
| • Ikegami HDK-55 | • Panasonic AK-HC3500 | • Sony PDW-F800 |
| • Ikegami HDK-5500 | • Panasonic AK-HC3800 | • Sony PMW-320 |
| • Ikegami HDK-77EC | • Panasonic AK-HC3900 | • Sony PMW-350 |
| • Ikegami HDK-79EC | • Panasonic AK-HC5000 | • Sony PMW-400 |
| • Ikegami HDK-95C | • Panasonic AK-HC931B | • Sony PMW-500 |
| • Ikegami HDK-970A/AP | • Panasonic AK-UC3000 | • Sony PXW-X320 |
| • Ikegami HDK-97A/AP | • Panasonic AK-UC3300 | • Sony PXW-X400 |
| • Ikegami Hi-Motion II | • Panasonic AK-UC4000 | • Sony PXW-X500 |
| • Ikegami SHK-810 | • Sony HDC-1700 | • Sony PXW-Z450 |
| • JVC GY-HM710 | • Sony HDC-2400 | • Sony PXW-Z750 |
| • JVC GY-HM750 | • Sony HDC-2500 | |

Always check the latest compatibility list at camRade.com. Please let us know whenever our information is incorrect or if the latest model is missing.

Technical Specifications

Accommodates	Wide range of cameras (see compatibility)
Max Lens Diameter	Ø 19 cm / 7.5"
Tripod mountable	Yes
Handheld	Yes
Shoulder	Yes
Colour	Black
Length	70 cm / 27.6"
Type of closure	Hook-and-loop & zippers
Zippers	Blue and black YKK®
Main material	420 Denier Nylon Fabric
Transparent	Clear Vinyl
Items included	Body cover & storage pouch
camRade lensC	Not compatible
Designed in	The Netherlands
Made in	China
Warranty	10-Year Warranty

Packaging



Weight: 0.75 kg / 1.65 lb

Why camRade?

camRade was established in 1998 and has an extensive track record of protecting broadcast and film cameras. Since the start of camRade, the team of people behind the brand have continued to work closely with several audio and camera operators, broadcasters, and rental companies. Today we can say that we are the recognised world leader in camera protection.

Why do I need a camRade rainCover?

Imagine how you would feel if your camera stopped working. A camera with water damage could be considered a total loss if the repair costs are too high. What if you could have prevented this by using a camRade rainCover? Your camera is often your most valuable piece of equipment while gathering news or during field productions. The durability and unique features of the rainCover ENG/EFP will protect your investment in a way that plastic bags and other cheap covers cannot.

Highlights / Unique Selling Points



Attach or detach the cover in seconds, whether used handheld or on a support plate.



Ability to operate the lens manually and access all control buttons.



Rubber strip on the front of the cover ensures seamless closure.



Quick access to the V-Mount / Gold Mount battery or optical cable connector.



Large zippered opening with extra protection on top gives access to the camera's carrying handle.



Small openings for antennas or wireless equipment and to attach the camera's carrying strap (with C-Clips).