

The Alpatron Cable Movers are designed to fit the 125 mm wheels of the Alpatron Pedestal Dolly. These instructions give you a mounting description and short information about the main functions of this accessory.

INSTRUCTIONS:

The 125 mm low friction swivel wheels can optionally be equipped with cable guards according to the following mounting instructions.



1. 125 mm Swivel Wheel
2. Washer 25 mm
3. Cable Guard
4. Washer 16 mm (2x)
5. Knob M8
6. Locking Plate
7. Hexagon Bolt M8x65

- Remove the Bolt and Nut from the 125 mm wheel using the supplied tools

- Take the new hexagon Bolt, Locking Plate and small washer and put them through the Bracket and Wheel.

- Then Position the Cable Movers (3) around the wheel and put the larger washer 25mm (2), the Cable Mover, a small washer (4) and the Knob on the Hexagon Bolt (7)

- Be sure that the locking plate (6) is put right to prevent the Bolt from turning when the Cable Mover is in place.

- Do so also for the other wheels

The Cable Mover now is mounted and adjustable by the Knob, shifting it vertically, depending on the use of the Pedestal.

